



INSTALLATION INSTRUCTIONS & DETAILS MODEL 1540-526-2 FLOOD VENT SEALING KIT-STACKER

877-441-8368 **SMARTVENT.COM**

INSTALLATION INSTRUCTIONS

- 1. PREPARE A CLEAN 16-1/4" WIDE BY 16-3/8" HIGH ROUGH OPENING (APPROX, 1 BLOCK WIDE X 2 BLOCKS HIGH) FOR EACH FRAME. ENSURE THE BOTTOM OF THE ROUGH OPENING IS NO MORE THAN 12" ABOVE THE FINISHED GRADE.
- 2. APPLY A BEAD OF HURRIBOND GRIP & SEAL OR EQUIVALENT ADHESIVE AROUND THE BACK OF THE FLANGE ON THE FRAME.
- 3. INSERT THE STACKER SEALING KIT FRAME INTO THE INTERIOR OPENING, 1540-521 (STACKER) WILL BE INSTALLED INTO THE EXTERIOR OPENING. 1540-521 MUST BE INSTALLED FOR EXTERIOR WALL APPLICATIONS.
- 4. WITH THE FRAME NOW IN THE OPENING, CHECK THAT THE FRAME IS SQUARE AND FIRMLY ADHERED.

DETAIL SPECIFICATIONS:

MATERIAL: STAINLESS STEEL - Powder Coat White Finish : Homasote®- Medium Density Fiber Board (Cellulose Based)

OPERATION: AUTOMATIC NON-POWERED ACTIVATION AND OPERATION

INSTALLATION:

SECURED W/ AN ADHESIVE (HURRIBOND)

HYDROSTATIC RELIEF: Coupled with 1540-521 Insulated Smart Vent to Provide 200 SQ. FT PER VENT (400 SQ. FT. PER THIS 2 UP ASSEMBLY)

NOTE: Wall must be minimum 7" thick to couple 1540-526-2 Flood Vent Sealing Kit (Stacker Model) with 1540-521 Flood Vent-Stacker.

COLORS: WHITE (STANDARD)

MEETS THE REQUIREMENTS FOR ENGINEERED OPENINGS AS SET FORTH BY: FEMA, NFIP, ICC, & ASCE SUPPORTIVE DOCUMENTS, TB 1-08, 44CFR 60.3(C)(5), ASCE 24-14 ICC EVALUATION # ESR-2074